

SPA-400 – ICOM A20, A21 Radio Installation Wiring Diagram

* ICS Load Modification

For more information about this resistor mod see the ICS Load Modification instructions.

File Name: ICS-Load_1440_Mod.pdf

Telephone: (909) 305-9399 E-mail:info@sigtronics.com Web: www.sigtronics.com

