



AIRCRAFT SPRUCE & SPECIALTY CO.
Worldwide Distributors of Certificated and Homebuilt Aircraft Supplies

Leading Edge Landing Light Kit

Installation Instructions

1. Cut open leading edge of each wing approximately 8 feet from the fuselage. Cut back to front spar.
2. Attach LARGE bracket between main nose rib and false nose rib.
3. Attach end of two wires furnished to light and install light into large bracket, by putting SMALL bracket over it, and tightening the 4 screws furnished.
4. Run light wires to switch on panel and from switch to electric source --- and ground terminal.
5. After finished and checked out, install sheet of Plexiglas or equal material over hole in each wing with metal screws and dope tape around edges.

Happy Night Flying!!!!

Please Note:

This kit does not include Plexiglas covering to cover leading edge of wing when finished. The best thin to do is purchase a small piece locally and form to your wing, with sheet metal screws, then dope tape around the edges.