


# RELAY DECK WIRING



## HAT SWITCH

Up - Orange  
Down - Black  
Left - Violet  
Right - Red  
Common - Green

## BUTTONS

Trigger\* - Yellow  
Index\* - Grey  
Right\* - Brown  
Left\* - Blue  
Common - White (trigger/index)  
and (left/right)

\* - All switches are momentary and can be used for radios, PTT, frequency change, auto pilot, disconnect, etc.

