


OIL PRESSURE GAUGE

Illustration of Instrument Connection :



NOTE :

- 1) Installing the instrument from behind the panel, use a 2-1/4" (57mm) hole . Use 4#40 screws to hold instrument secure.
- 2) The gauge is compatible with original ROTAX 4~20mA at 0.75~10.75bar output pressure sensor or the 0.5~4.5V output one from CF. When using the 4~20mA output sensor, refer to the illustration on the left. When using the 0.5~4.5V output sensor, refer to the illustration on the right. Note: after cutting the wire, ensure that no touch or conduction between the four leads.
- 3) Mount at least 12" away from compass.
- 4) This unit has not been approved for type certified aircraft.
- 5) Do not connect instrument to any other power source. Damage may occur.