

Thank you for your order of the Tally-Lok₁₁ Rudder Gust Lock for your Cessna.

It is highly recommended to install the rudder lock on the side of the cockpit from which you fly.

DO NOT OVERTIGHTEN!!! The lock is capable of a 150lb load.

Squeeze until there is enough pressure to keep the pedals stationary and keep the lock securely in place.

To release, press the silver tab forward.

Never lubricate the gust lock.

Installation of this gust lock will not set the brakes.

Aircraft should not be towed with Tally-Lok_™ rudder gust lock installed. However, if towing occurs, up to 20 degrees of nose gear travel is safe without causing damage to the aircraft. (Window sign provided below)

The Tally-Lok_™ Extension must be attached to the back of the lock and NOT to the silver rod side. <u>Red to Red.</u>

Feel free to contact us any time if you have questions or concerns.



RUDDER GUST LOCK INSTALLED



TALLY-HO AVIATION, LLC. 53 MIRY BROOK ROAD DANBURY, CT 06810

203.733.9045 kari@tally-hoav.com

Pictured: Installation examples for...

C-150 & C152 Slant Tail C-140 & Early C-150 Straight Tail





Cessna 177 Cardinal





Cessna 170



4-seat Cessna with articulating seats

4-seat Cessna Non-articulating sets



