

PIPER PARTS

(FAA/PMA APPROVED)

PIPER NOSE COWLING (ALL METAL)



PA 12 & 14



PA-20-22

J-3 & PA-11

Description	Part No.	Price
PA-11, For cowls using screws	P/N 05-07295	
PA-11, For cowls using Lion fasteners	P/N 05-07305	
J-3 Eyebrow baffle LH.....	P/N 05-00061	
J-3 Eyebrow baffle RH.....	P/N 05-00062	
Front piece for Top cowl.....	P/N 05-00063	
Top cowl for J-3.....	P/N 05-00064	
Bottom cowl for Continental powered J-3	P/N 05-00065	
Front piece for bottom cowl.....	P/N 05-00066	
Fuselage cowl	P/N 05-00067	
Top cowl for PA-11.....	P/N 05-00068	
Bottom cowl for PA-11	P/N 05-00069	
Side cowl for PA-11LH.....	P/N 05-00071	
Side cowl for PA-11 RH	P/N 05-00072	

PA-12

Bottom cowl.....	P/N 05-00078	
Top cowl	P/N 05-00079	
Fuselage cowl	P/N 05-00081	
Left side cowl.....	P/N 05-00082	
Right side cowl	P/N 05-00083	

PA-12 & 14

Nose cowl for all serial numbers	P/N 05-07310	
--	--------------	--

PA-18 (95 HP)

PA-18, For cowls using screws	P/N 05-07295	
PA-18, For cowls using Lion fasteners	P/N 05-07305	
Left side cowl, used w/shielded ignition lead ..	P/N 05-00073	
Right side cowl, used w/shielded ignition lead..	P/N 05-00074	
Top cowl	P/N 05-00075	
Bottom cowl.....	P/N 05-00076	
Bottom cowl, installed w/machine screws...P/N	05-00077	

PA-18 - 105, 125, 135, 150 HP

Fuselage cowl, S/N 2168-5938,105, 125,135HP	P/N 05-00089	
Fuselage cowl, S/N 5939-8019, 135, 150 HP ..	P/N 05-00091	
Fuselage cowl, S/N 8020 and up, 150 HP..P/N	05-00092	
PA-18-105 thru 125 HP, no starter hole.....	P/N 05-07315	
PA-18-105 thru 125 HP, with starter hole ...P/N	05-07320	
PA-18-135 & 150 HP, w/starter hole & oil scoop	P/N 05-07325	
PA-18-135 & 150 HP, w/oil scoop, no starter hole	P/N 05-07330	
Top cowl, 105 HP	P/N 05-00093	
Top cowl, 125, 135, 150 HP.....	P/N 05-00094	
Left side cowl, 105 HP	P/N 05-00095	
Right side cowl, 105 HP	P/N 05-00096	
Left side cowl, 125, 135, 150 HP	P/N 05-00097	
Right side cowl, 125, 135, 150 HP.....	P/N 05-00098	
Lower cowl ass'y, 135 HP, S/N 3014 thru 4617	P/N 05-00099	
Lower cowl ass'y, 150 HP, S/N 3771 thru 6963	P/N 05-04784	
Lower cowl ass'y, 150 HP, S/N 6964 and up	P/N 05-00102	

PA-20 & PA-22

PA-22-108, S/N 8000 & up, w/o oil scoop ..P/N	05-07345	
PA-20 Nose cowl, 115 HP.....	P/N 05-07335	
PA-22 Nose cowl, S/N 1 thru 533	P/N 05-07335	
PA-20 Nose cowl, 135 HP.....	P/N 05-07340	
PA-20 Bottom cowl, 125 HP.....	P/N 05-00049	
PA-20 Bottom cowl, 135 HP	P/N 05-00051	
PA-22 Bottom cowl, 125 HP, S/N 1 - 353 ..P/N	05-00052	
PA-22 Bottom cowl, 125 HP, S/N 354 - 533..P/N	05-00053	
PA-22 Bottom cowl, 125 HP, S/N 534 - 1759 ..P/N	05-00054	
PA-22 Bottom cowl,135-160HP, S/N 1760-7630	P/N 05-00055	
PA-22(Colt) Bottom cowl, 108HP, S/N 8000 &up	P/N 05-00056	
PA-22 Left side cowl	P/N 05-00057	
PA-22 Right side cowl	P/N 05-00058	
PA-20/22 Top center cowl.....	P/N 05-00059	
PA-25 Pawnee Nose cowl, 150 HP	P/N 05-07340	


ONE PIECE STAMPED ALUMINUM RIBS (STC APPROVED)



These durable ribs are direct replacements for the original style "Truss" type ribs originally used by Piper. These ribs are designed for the various modes of Piper including J-3 and PA-18 with metal spars. The ribs listed are the more commonly requested ribs for this series.

Description	Part No.	Replaces	Price
Nose Rib.....	P/N 05-02389	12662-002	
Nose Rib, Tip R/H	P/N 05-07375	16192-001	
Full Rib	P/N 05-07380	13052-002	
Full Butt Rib, L/H	P/N 05-07385	10634-000	
Full Butt Rib, R/H	P/N 05-07390	10634-008	
Full Tank Bay Rib, L/H	P/N 05-07395	10653-000	
Full Tank Bay Rib, R/H.....	P/N 05-07405	10653-006	
Full I.B. Ail. Bay, L/H	P/N 05-07410	13022-000	
Full I.B. Ail. Bay, R/H.....	P/N 05-07415	13042-001	
Full O.B. Ail. Bay, L/H	P/N 05-02387	12902-000	
Full O.B. Ail. Bay, R/H.....	P/N 05-02393	12902-001	
3/4 Rib.....	P/N 05-07430	13022-002	
3/4 Butt Rib, L/H.....	P/N 05-02396	10634-005	
3/4 Butt Rib, R/H	P/N 05-07440	10634-007	
3/4 Tank Bay Rib.....	P/N 05-02397	10635-002	

STABILIZER LINER TUBE



Forward Link Assembly Liner Tube (U86062-080).....P/N 05-07450
Rear Liner Tube (U86062-079).....P/N 05-07455

STABILIZER YOKE & ADJUSTMENT SCREW



Yoke

Adjustment Screw

CA452-538

PIPER STABILATOR BEARING



CA452-538 Piper stabilator bearing.
P/N 05-04626

WING NAVIGATION LIGHT BRACKET



For use with Grimes Model "E" Type Light or equivalent.
P/N 05-07460

ENGINE MOUNTS



J-3 Continental Mount

PA-11 Mount


J-3, PA-11, PA-18



Left Gear, uncovered

Right Gear, uncovered

PIPER METAL WING SPARS



Piper Metal Wing Spars. Metal spar. Applicability: Piper J-3, PA-11, PA-18-95. Highlighted part in illustration. FAA/PMA approved.

Description	Part Number	Price
J-3 & Pa-11 Front LH Wing Spar	05-00875	---
J-3 & Pa-11 Front Right Wing Spar	05-12728	---
J-3 & Pa-11 Rear LH Wing Spar	05-06993	---
J-3 & Pa-11 Rear Right Wing Spar	05-12729	---

PIPER HEATER TEMPERATURE CONTROL LOCK



For years Piper PA28 and PA32 owners have been plagued with a Heater Temperature Control that will not stay positioned. This Heater Temperature Control Lock that can be installed in minutes and provides a positive adjustable lock for the Heater Control Lever.
P/N 08-04939

VERTICAL FIN EXP40592-00



Vertical Fin for Piper J-3/PA-11/PA-18. Experimental Only. Duplicate Part. Built to the same specifications as OEM 40592-00.....P/N 05-12467