ΕL

WHELEN STROBES

STROBE SYSTEM PARTS

			ODE 3
Model No.	Description	Part No.	Price
A402R	Red Optic Lens	11-03254	
A402W	White Optic Lens	11-03271	
A402R/W	Split Red/White Optic Lens	11-03248	
A406	Flash Tube Assembly	11-03687	
A409	Clamp Ring Assembly	11-03688	
A414A, HDH, CF	HDH,CF Power Supply	11-03632	
A417-1	Interconnecting Cable	11-03658	
A421-1	Warning Decal	11-03691	
A425	Tail Strobe Lens Retainer	11-03692	
A426	Wingtip Strobe Lens Retainer	11-03233	
A427	Flash Tube Assembly	11-03219	
A427-M	Flash Tube Assembly with Molex Connector	11-03272	
A427-4	Rubber Pad Spacer	11-03693	
A428	Wingtip Strobe Lens	11-03236	
A428-C	Wingtip Strobe Radio Shielded Lens	11-03694	
A428-D	Wingtip Strobe Radio Shielded Lens plus A426 Retainer Assembly	11-03290	
A469A	Strobe Tube Assembly	11-03242	
A430	Tail Strobe Head Assembly	11-03696	
A435	Flash Tube Assembly	11-03697	
A440	WRM-65 Mounting Adapter, for HR,DF & SA,DF	11-03699	
A441	AMP Connector and 3 Pins	11-03211	
A442	AMP Connector and 3 Sockets	11-03212	
M441	Molex Connector and 3 Pins for Piper Installation	11-04215	
M442	Molex Connector and 3 Sockets for Piper Installation	11-04216	
A444	AMP Connector and 2 Pins	11-03700	
M444	Molex Connector and 2 Pins for Piper Installation	11-04217	
A445	Switch Label	11-03701	
A446	AMP Connector and 2 Sockets	11-03702	
A450	Strobe Head Assembly	11-03280	
A455	Gasket	11-03703	
A457A	Tail Light Lens for A500 and A555	11-03227	
A457A-D	Radio Shielded Tail Light Lens Assembly for A500	11-03704	
A466A-1	Radio Shielded Lens	11-03708	
A467	Gasket for A470	11-03709	
A469B	Flash Tube Assembly	11-03225	
A469D-K	Radio Shielded Kit for A469A	11-03711	

Model No.	Description	Part No.	Price
A470-D	Radio Shielded Remote Strobe Head Assembly, Specify Color	11-03291	
A470-A-D-S	Strobe Head Assembly, Shielded Red/White	11-04976	
A470-D-R-SU	Radio Shielded Remote Strobe	11-03714	
A490 TC CF	14V Power Supply	11-02661	
A500-V-D-28	28V Radio Shielded Tail Position Strobe Light Head Assembly Vertical Mount	11-06407	
A500-V- D-M-14	Radio Shielded Tail Position & Strobe Light Head Assembly Vertical Mount with Molex Connector	11-03722	
A500B-V-14	Tail Position & Strobe Light Head Assembly (Beech)	11-03715	
A500B-V-28	Tail Position & Strobe Light Head Assembly (Beech)	11-03716	
A502	Flash Tube & Socket Assembly	11-03723	
A506	Flash Tube & Socket Assembly	11-03274	
A506-B	Flash Tube & Socket Assembly	`	
A506-M	Flash Tube & Socket Assembly	11-03725	
A506-SP	Flash Tube & Socket Assembly	11-03726	
A507	Lamp Socket Assembly for A555	11-03240	
A508-14	Halogen Lamp for A500, A555, A600	11-03216	
A508-28	Halogen Lamp for A500, A555, A600	11-03208	
A509	Lamp Shield for A500 and A555	11-03727	
A510-28	Lamp Assembly for A500 & A555	11-03266	
A50828	Lamp for A500, A555, & A600	11-03208	
A512-V-28	Tail Position & Strobe Light Head Assembly (Gulfstream Commander)	11-03729	
A540	Long Mounting Adapter	11-03730	
A605	Base Plate Assembly	11-03733	
A606	Retainer	11-03260	
A610	Flash Tube Assembly	11-03213	
A610-M	Flash Tube Assembly	11-03734	
A612	Magnifying Lens	11-03222	
A612-D	Radio Shielded Lens Retainer Assembly	11-03735	
A615	Lens for A600 Tail Light	11-03230	
A616	Gasket for A600 Tail Light	11-03261	
A625	Tail Strobe Head	11-03228	
A625-D	Radio Shielded Tail Strobe Head Assembly	11-03659	
A626	Retainer Lens	11-03229	
A626-D	Radio Shielded Lens Retainer Assembly	11-03736	
A627	Flash Tube Assembly	11-03263	
A628	Retainer Lens	11-03737	
A629	Gasket	11-03660	
A650	Wingtip Strobe Head Assembly	11-03215	